

Enola Gaye WP40 pin-activated smoke grenade - 90 seconds

https://europarm.fr//en/produit-12440-Enola-Gaye-WP40-pin-activated-smoke-grenade-90-seconds













Plus de visuels disponibles sur le site



SKU	Designation	French Law	Width (cm)	Height (cm)	Weight (g)	Colors	MSRP
A705302B	Blue Smoke	Vente libre	3.8	13	140	Blue	6.10 € incl. tax
A705302N	Black Smoke	Vente libre	3.8	13	140	Black	6.10 € incl. tax
A705302	Red Smoke	Vente libre	3.8	13	140	Red	6.10 € incl. tax
A705302BC	White Smoke	Vente libre	3.8	13	140	White	6.10 € incl. tax
A705302O	Orange Smoke	Vente libre	3.8	13	140	Orange	6.10 € incl. tax
A705302V	Green Smoke	Vente libre	3.8	13	140	Green	6.10 € incl. tax
A705302VI	Purple Smoke	Vente libre	3.8	13	140	Purple	6.10 € incl. tax
A705302J	Yellow Smoke	Vente libre	3.8	13	140	Yellow	6.10 € incl. tax
A705302RS	Pink Smoke	Vente libre	3.8	13	40	Pink	6.10 € incl. tax

Enola Gaye For over 20 years, the company has been designing high-performance civilian smoke generators, combining compactness, safety, and spectacular visual effects. Products in the WP40 range are used worldwide for their ease of use and consistent smoke quality.

The most widely used compact smoke grenade in Europe for airsoft, simulation and signaling!

Ideal for concealing your movements and advancing without being seen by your opponents.

- Pin activation system
- Burning time between 90s (+/- 20s)

This type of smoke grenade is ideal for confusing your opponents with a thick fog. These smoke grenades are widely used in airsoft and paintball during assaults. They're perfect for concealing your movements and advancing undetected.

■ Dimensions: 40 mm x 130 mm.

■ Weight: 140 g.

Active ingredient weight: 50 gWater resistant: yes, partially

■ Pin activation system

■ **Burning time 90s** plus or minus 20s

■ Ask for Enola Gaye smoke grenade display stands for your store!

Safety instructions

CAUTION: Hot gases, sparks, or ash may be emitted during ignition or operation. If you intend to hold the appliance while it is in operation, wear gloves and safety glasses. Otherwise, pull the cord to ignite the appliance, then immediately place it on a non-flammable surface, maintaining a safe distance of 2 meters. Follow all instructions and warnings on the product label. For outdoor use only.

Les prix de vente conseillés sont mentionnés à titre indicatif. Les armuriers sont libres de vendre au prix qu'ils souhaitent. Textes et photos non contractuels, sujet à modification.