



NUM'AXES

SKU	Designation	French Law	Length (cm)	Diam. (mm)	Weight (g)	Lumens	Battery	Colors	MSRP
NUM667	Num'Axes LMP1018	Vente libre	17.1	50	275	1000	Rechargeable	Black	68.00 € incl. tax

### Tactical flashlight with switch tip on body.

Focused beam torch equipped with a 1000 lumen LED for 3-level lighting:

- Intense: Range 500 m - autonomy 2 h
- Low: Range 228 m - autonomy 4 h
- Strobe
- Withstands a drop of 1m, waterproof IP44

LED torch supplied with 1 rechargeable 26650 4000 mAh 3.7 V battery, 1 battery charger (recharging is done without removing the battery), 1 wrist strap and 1 user guide.

Interview :

Gently blow away any dust or debris from the lens (or use a soft lens cleaning brush). To remove dirt or fingerprints, clean with a soft cotton cloth using a circular motion. Using a rough cloth or rubbing the lens unnecessarily can scratch it and potentially cause irreversible damage. For a more thorough cleaning, use a lens cleaning cloth and a photographic lens cleaning solution, or isopropyl alcohol. Always apply the liquid to the cloth and never directly to the lens. Cleaning your flashlight's contacts occasionally improves its performance. Dirty contacts can cause the flashlight to flicker, turn on intermittently, or not turn on at all.

Every 6 months, clean the threads on the battery compartment cover and the flashlight tube with a dry cloth, then apply a thin layer of silicone lubricant to the rubber O-ring. Never remove the lens head or any of the internal components. Doing so could damage the flashlight and void your warranty.

Precautions for use:

- Fully charge the battery before first use.
- The 1000 lumen LED flashlight is a high-intensity lighting device capable of causing eye damage. Avoid shining the light directly into someone's eyes.
- The operating time of your flashlight depends on whether it is used continuously or intermittently. Intermittent use will extend the battery life.
- The LED is a light source that will function for the entire lifespan of the lamp. It will never need to be replaced.
- Remove the battery when you are not using the lamp for an extended period.
- Because LED flashlights are high-intensity, they can reach high temperatures. It is normal for the aluminum body of the flashlight to become very hot during continuous use.
- Keep it away from children. Handle it with care.

*Les prix de vente conseillés sont mentionnés à titre indicatif. Les armuriers sont libres de vendre au prix qu'ils souhaitent. Textes et photos non contractuels, sujet à modification.*